

Documentation / Adjust Titel Block



Content

Adjust the address and company LOGO In the plan header	2
Import standard title block.....	3
Adjust title block.....	4
Insert company logo	6
Place the new title block in the correct folder	7

10/2019

Adjust the address and company in the plan header

INDEX	DATUM	KORREKTOR	AENDERUNG
Example Company Ltd. postal code, city, address phone fax e-mail info@ http://www.			Firma Company Société Customers' name
			Projekt Project Projet Project
			Projektteil Part of project Partie du projet Part of project
			System System Système LOGO
			Maßstab Scale Echelle 1:50
			Vorgang File Affaire Version Version Version

To be able to edit the title block, you first have to create a new drawing. Which project you choose does not matter.

Alternatively, you can also create a new project.

Project
Planning
Delivery
Warehouse stock

Project

Project number

Project name (*)

Project part (*)

Note

Status

Customer

Customer (*)

Customer number

Project address

Place

Street

Project no. Yard no.

Note

Country (*)


Contact


Contact

Telephone

Email


After confirming the function "New design", PPL automatically switches to the "Design" module.





Import standard title block

Select "Import" and open an existing title block.



The templates can be found in the following directory.

C:\PPL\ERP\ERPConfig\docdb\0\templates\titleblocks

The command "Zoom all" displays the template in full screen.



INDEX	DATUM	KORREKTOR	AENDERUNG
Firma PLZ Ort und Strasse Telefon (+49) Fax (+49) e-mail info@ http://www.			Firma Company Société PASCHAL-Werk G. Maier GmbH
			Projekt Project Projet Documentation English
			Projektteil Part of project Partie du projet Examples
			System System Système - Keine -
Maßstab Scale Echelle 1:1		Datum Date Date 25.03.2012	Name Name Nom ppladmin
			Blatt Sheet Feuille - Modell -
Vorgang File Affaire			Version Version Version

Adjust title block


Double-clicking with the left mouse button on the desired text opens a text field. Change the corresponding text content as desired and then confirm with "OK".



Different text boxes are placeholders. In the final formwork plan, the corresponding information from the project mask is automatically entered here.


Firma Company Société	planitec GmbH		
Projekt Project Projet	Documentation English		
Projektteil Part of project Partie du projet	Examples		
System System Système	- Keine -		
Maßstab Scale Echelle	1:1	Datum Date Date	25.03.2012
		Name Name Nom	ppladmin
		Blatt Sheet Feuille	- Modell -
Vorgang File Affaire		Version Version Version	

If required, these Variables can also be changed in the "Properties".




Insert company logo

Select the "Adding graphic" command in the menu "Draw2D".




Then select the graphic file with your company logo and confirm with „Öffnen“




When pasting, the size of the graphic can be dynamically adjusted. In addition, the graphic element can then be copied or moved.






Move the logo from a point to a specific point.

If the title corresponds to your requirements, the current status should be saved.




Place the new title block in the correct folder

To be able to select the finished title block in all formwork plans, first save the file on the desktop with "Export".



You can give the file an arbitrary name and confirm with „Speichern“ (save).



Then place the title in the following directory:

C:\PPL\ERP\ERPConfig\docdb\1\templates\titleblocks

After restarting PPL, the new or modified header will be available in the Plan Manager when creating a new plan.

According to the previous steps, any template can be edited and adapted to your needs.